

User Manual

I. INTRODUCTION

To ensure your safety and the safety of others, please ensure that you read all the safety information before operating this product.
Keep this information in a safe place for future reference.

This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Safety Considerations.

- Position the cables so that they cannot be walked on or pinched by items placed on or against them.
- Do not use the set top box in humid or damp conditions.
- Do not allow the set top box to get wet.
- Do not expose the set top box to dripping or splashing.
- Do not place water filled objects such as vases on top of the set top box.
- Do not place naked flame sources, such as candles, on the top of the set top box.
- To prevent direct exposure to the laser beam, do not open the enclosure.
- Never stare directly into the laser beam.

Ventilation

The slots and openings on the set top box are for ventilation. Do not cover or block them as it may cause overheating.
NEVER let children push anything into the holes or slots on the case.

Battery Disposal

Please ensure batteries are disposed of safely.
Never dispose of batteries in a fire or with other household waste.
Check with your local authority for disposal regulations.

Cleaning

ALWAYS unplug the product before you clean it.
Do not use liquid or aerosol cleaners.
Clean the set top box with a soft, damp (not wet) cloth.

M3700 handling and care	
Place the product in a well-ventilated area	Don't install it in the cold or under direct sunlight
	
Leave a minimum 10cm gap all around the product	Do not disassemble, repair, or reorganize the product
	
Don't place cups with water or other liquids on the top of the product	Don't place objects on the top of the product
	

2. CONTROLS AND CONNECTIONS



1. Media selection.
2. Navigation buttons and OK. Used to browse the menus and to confirm selection.
3. Main menu in DVD mode.
   File browser in USB mode.
   Setup menu in DVB-T mode.
4. On/Off switch.
5. Battery-charge indicator.
6. DC Power connection DC (12 V)
7. 3.5 mm (1/8") Stereo earphone output.
8. 3.5 mm (1/8") TRRS A/V output.
9. Volume control.
10. USB host port (Type A).
11. Antenna coaxial connector.

For disc loading slide the screen part to the top. In that position you can place the disc easily. Then move smoothly the screen part back to its closed position.
Note: Load the disc on the tray with printed side facing up.



3. REMOTE CONTROL

3.I. BUTTON DESCRIPTION



1. MUTE: Mute/unmute the sound.
2. 4:3/16:9: Switch between normal and panoramic mode.
3. VOL +/-: Change the volume.
4. SCAN.
5. FAVORITE: Access your favorite channels.
6. SETUP: Access the setup menu.
7. Navigation buttons: Used to browse the menus.
8. OK: Confirms the selection.
9. EXIT: Return to the previous screen or menu.
10. INFO: Display information about the channel being viewed.
11. AUDIO: Selects between available audio tracks or sets the sound mode as LR (stereo), LL (left) or RR (right).
12. PLAY/PAUSE: Pause or resume the playback.
13. STOP: Stops the playback.
14. REV: Fast backward at selectable speeds.
15. FWD: Fast forward at selectable speeds.
16. REPEAT: Switches between the different repeat options.
17. A-B: Define and repeat a sequence.
18. SPEAKER: Enables/disables the integrated speakers.
19. TFT ON/OFF: Enables/disables the screen.
20. Numeric Keys: Select channels or numbers in the menus.
21. GOTO: Go to a specific point of time when playing a video or audio file.
22. FUNCTION.
23. TV/RADIO: Switch between TV and radio channels.
24. SOURCE: Switch between DVD/USB/DVB-T.
25. TITLE/TTX: Title menu when in DVD mode / Teletext in DVB-T mode.
26. EPG/PROG: Electronic Program Guide when in DVB-T mode or Programmed playback when in DVD mode.
27. SUBTITLE: Switch among available subtitles.
28. ZOOM: Enlarge the image.
29. PBC: Enable/disable PBC mode when playing VCD.
30. MENU: DVD main menu.
31. PREVIOUS: Go to previous chapter/track/file.
32. NEXT: Go to next chapter/track/file.
33. ANGLE: Switch among available camera angles (DVD).
34. SLOW: Slow playback.

Note: SUBTITLES/TEXT/AUDIO may not be available for all channels.

3.2. BATTERY

Pull the battery loader out and insert a CR2025 battery.



Make sure to place the battery in the correct direction.

When not using the remote control for a long time remove the battery.

When operating range reduces replace the battery.

4. SETUP

4.1. INSERTING A DISC

1. Press the SOURCE button on the remote control and use the up/down buttons to select the source: DVD-ROM Drive. Press the OK button to confirm.
2. Follow the instructions in "Controls and Connections" to open the disc cover.
3. Insert a disc, then close gently the cover. The unit will read the disc and start to play it, or it will display a start menu

4.2. CONNECTING A USB DEVICE

Connect a USB device to the unit. Press the SOURCE button on the remote control and use the up/down buttons to select the source: DVD, DVB or USB. Press the OK button to confirm.

4.3. DVB-T FIRST TIME INSTALLATION

When DVB mode is used for the first time, the screen will display the First Time Installation page. This will guide the user through the initial DVB mode setup.
First, choose "Yes", then press the OK button. The system will then start the initial setup.
Then select the relevant regional information (country, OSD language and Time Zone). The system will automatically scan through the channels according to the information you have entered.
Select "Yes" to start the automatic search.
At the end of the search, the system will go to DVB mode in order to view the channels found.

5. MAIN MENU

The main menu allows you to access DVD Setup, DVB Menu, System Setting and Game. Press the SETUP button to access the main menu.

5.1. DVD SETUP

5.1.1. Language Setup

- Menu: To select the disc menu language.
- Audio: To select the audio language.
- Subtitle: To select the subtitle language.
- External Subtitle: To select an alphabet for the MPEG4 subtitle language.

5.1.2. Audio Setup

- Downmix
  Lt/Rt: Select this option when connected to a Dolby Pro Logic compatible sound device.
  Lo/Ro: Select when connected to a standard stereophonic sound playback device such as hi-fi or headphones.

5.1.3. Custom Setup

- Parental Ctrl
  Select a level and press OK to confirm. Then enter the default password “6666” and press OK to confirm. If you forget the password, you can always use the default password “6666”.
- Angle Mark
  On: Enable the angle mark function. Off: Disable the function.

5.2. DVB-T MENU

In DVB mode, press the SETUP button to enter the main menu and select “DVB menu”.

5.2.1. Program List

- TV Program
  The table has three options: Favor, Move and Del.
  Favor
  You can use this option to select your favorite channels. Go to the “Favor” box corresponding to the channel which you want to add to your favorites and press OK. Once a channel is chosen, a symbol (heart) will appear in the corresponding “Favor” box. To remove a channel from the favorites list, select the channel and press OK. You can then use the FAVORITE button to access your favorite channels.

Move

This option allows you to change the order of channels on the list. Go to the "Move" box corresponding to the channel that you want to move. Press OK, then use the up/down buttons to move the channel. Then press OK to confirm.

Del

You can use this option to delete channels. Go to the "Del" box corresponding to the channel that you want to delete, then press the OK button. An 'X' will appear. This channel will not appear the next time the list is displayed.

- Music Program

  The list of radio stations is displayed in the same way as the list of TV Channels. Please refer to the previous section to edit the radio station list.
- Sort

  You can sort channels on the list by Name (channel name), Service ID, Channel No. (number) or LCN (Logic channel number).

5.2.2. Channel Search

- Automatic Search

  This option enables the user to search for channels automatically according to the Country and Time Zone settings. Before starting a search, the system will ask whether existing channels in the program list should be deleted. Choose "Yes" to replace the old channels with the new channels. Choose "No" to add the new channels to the list. When the automatic search is over, DVB mode will close and the unit will return to the channel display mode. If you press the RETURN/EXIT button to suspend the search, the new channels will be added to the list and the unit will show the last channel found.
- Manual Search

  Use manual search to find a particular channel. You must provide the system with the channel number and confirm with the OK button. The channels found during the manual search will be added to the list but the unit will not exit the menu automatically.

5.2.3. Parental control

- Channel Lock

  Select Channel Lock to block certain channels. To activate the channel lock ("Yes"), no code is needed. But to disable the channel lock ("No"), the user must enter the code.
- Parental Setting

The Parental Setting can be used together with the Channel lock to lock channels. In order to enter the Parental Setting page, you must enter the PIN code. This menu enables you to select the channels to be locked. To view the locked channels, the user must enter the correct PIN code.

Note: the default PIN code is 6666. To change it, return to Main Menu and select "System Setting", then enter the System Setting Menu-Preference page and select the "Change PIN" option.

5.2.4. DVB-T Setting

- Country
  Select this option to set the country for receiving DVB signals.
- Language
  The Language submenu has 3 options:
  "Audio I" and "Audio 2": The user can choose the audio language from "Audio I"or "Audio 2".
  Subtitle: Select this option to choose the subtitle language.
  The Language option only works when the channel offers several languages. Otherwise, the preset language of that channel will be chosen automatically.
- GMT Usage
  Select this option to turn GMT usage on/off. When it is "Off", the Time Zone option will not be available and you must set the time yourself. When it is "On", you can select the Time Zone for your location.
- Time Zone
  Select this option to set your time zone.
- System Schedule
  Select this option to preset the time for changing the channel. You can preset up to 10 channels.

5.3. SYSTEM SETUP

5.3.1. Language Setup

- OSD: To select the on-screen display language.

5.3.2. Display Setup

- TV Standard
  You can select one of the following systems: NTSC, PAL and AUTO (Multi). Select the system that matches your TV.
- Display type.
  4:3PS – Select this format to display 4:3 images without distorting the picture. In this case, black bands will appear on left and right of the screen.

4:3LB – Select this format when the unit is connected to a 4:3 TV. Wide-screen images will be shown in full with black bands at the top and bottom of the screen.
I6:9 – Select this format to play wide-screen videos in full-screen mode.

5.3.3. Preferences

- UI Style
  Four setup menu styles can be selected.
- Change PIN
  Change the parental control password. The default is "6666".
- Default Type
  DVD/DVB/USB/User Select/Last Operating Type: Select the default source when the unit is switched on.
- Default
  Read: Restore the factory default settings.
- System Info
  The system information includes the Model, HW (hardware), SW (software) and Date.

5.4. GAME

Three games (Mine, Tetris and Rush Hour) and Calendar.

6. PLAYING DVD / CD / VCD DISCS

- Play/Pause
  Press to start playback. Press this button again to pause playback.
- Slow
  Press the SLOW button to start forward slow motion play. Each time the Slow button is pressed, the playback speed will change as follows: 1/2, 1/4, 1/8, 1/16, 1/32. Press the Play/Pause button to return to normal playback.
  Note: Slow motion is not available when playing a CD.
- Fast forward/backward
  Press the FF/FB buttons to perform a fast forward or backward search. Press the Play/Pause button to return to normal playback. Each time these buttons are pressed, the playback speed will change as follows: x2, x4, x8, x16, x32.
- Skip Forward/Backward
  When a disc is playing, you can skip backward/forward to the next track or chapter.
  For audio CD discs, use the number buttons 0-9 to directly enter the number of the track you want to listen to.
- Stop
  Press Stop once to interrupt playback. Press Play/Pause to resume playback from the point where the disc was stopped.
  Press Stop twice to stop playback completely. It is now impossible to resume playback from the place where playback was stopped. Press Play/Pause to start playback from the beginning of the disc.
- Menu
  Press to display the disc menu. This button has no function when playing an audio CD.
- Title
  Press to display the DVD title menu (the availability of this function depends on the disc).
- Zoom
  The picture size can be magnified during playback.
  When a disc is playing, press the Zoom button. Each time the Zoom button is pressed, the image size will change as follows: x1 -> x2 -> x4
  While an image is magnified, use the arrow keys to pan the image for viewing.
  To return to the normal view, press the Zoom button until the message x1 appears.
- Angle
  Change the viewing angle on a DVD. This button enables you to view a scene from different angles (the availability of this function depends on the DVD). Press Angle repeatedly to select different

viewing angles.

- Audio

  Select from the audio languages available on the disc. When a disc is playing, press Audio to show the current audio language. Press repeatedly to select the desired audio language.

  Note: You can select the audio output when playing a VCD disc: L/L (Left), R/R (Right), L/R (Mix). There will be no sound output when DTS audio format is selected.

- Subtitle

  To select one of the subtitle languages available on the disc.

  During playback, you can change the subtitle language or disable the subtitle function.

  While a disc is playing, press Subtitle to show the current subtitle language.

  Press repeatedly to select the desired subtitle language.

- Display

  While a disc is playing, press to show playback information available, depending on the disc.

- GoTo

  Select a specific title/chapter on a DVD or time on a CD/VCD.

  Press Left/Right to highlight the title / chapter (DVD) or time (CD/VCD) field or enter the relevant number using the numeric keypad.

  Press OK to confirm. The unit will then start playback from the selected position.

  Note: Some discs may not allow use of this function. For VCDs, this function is only available if PBC is off.

- Program

  The contents of the disc can be played in a selected order.

  Note: During VCD/SVCD playback, this function is only available when PBC is OFF.

  Use the Up/Down buttons to select the title number to the right of the program menu and press the OK button. Use the Up/Down buttons to select a chapter number and then press OK to confirm your selection. The selected program number "xx--xx" will be displayed to the left of the program menu.

  Repeat the above step for the next titles/chapters (or tracks in CDs).

  Press Play/Pause or OK to start the programmed playback.

  Refer to the previous section to program the tracks of your choice.

  Select the item and then press Stop to delete it.

- Repeat playback

  A specific title, chapter or track can be played repeatedly.

  Note: During VCD / SVCD playback, repeat playback is only available when PBC is OFF.

  REPEAT button:

DVDs: Off > Chapter > Title
CD /VCD/SVCD: Off > Track > All
MP3 / JPEG / WMA files: Off > Track > Folder > Al

A-B button:

Press the A-B button to set the start of the section (point A).

Press the A-B button again to set the end of the section (point B).

The unit will then immediately begin replaying the selection (A to B) repeatedly.

Press the A-B button again to clear the programmed repeat playback and return to normal playback.

Note: The A-B repeat function can only be used within the same title or track. If points A and B are defined in different titles or tracks, A-B repeat is cancelled.

7. PLAYING MP3 / JPEG / WMA / MPEG 4 FILES

Note: This unit does not support the DIVX3 format.

- Play/Pause
  Press to start playback. Press again to pause playback.
- Skip
  Press to skip to the next/previous track or picture.
- Stop
  Press to stop playback and display the selection menu (JPEG and movie files).
  Note: Press to play from the beginning.
- Zoom
  Press to zoom in on an image when playing JPEG or MPEG4 files.
- Flipping and rotating images (JPEG)
  Press the navigation keys to flip or rotate an image.
- Selection Menu
  I. Press Stop to display the root menu.
  2. Press the navigation keys to select a folder or file and then press the OK button to confirm.
  JPEG files:
  Press Play/Pause to start a slideshow from the JPEG file currently selected. You can then zoom or rotate the images displayed. Press the ANGLE button repeatedly to select a different transition mode. During playback, you can press the MENU button to return to the root menu or press the Stop button to display the JPEG files in thumbnail mode and you can then select “Rotate” or “Slide Show”.

8. DVB-T OPERATION

Press the SOURCE button on the remote control and use the Up/Down buttons to select DVB. Press the OK button to confirm.

- Selecting a Channel
  Press CH-/CH+ to go through the channels or press the numeric buttons on the remote control. In normal playback mode, press the OK button to display the channel list on the screen. You can then select which channel you want to watch.
- Audio
  Press the Audio button to choose the audio channel (Audio I or Audio 2) and three audio modes: LL, RR and LR.
- Subtitles
  Press the Subtitle button to choose the subtitle language. The number of available languages depends on the channel. If no other language can be chosen, only the "off" option will be available.
- EPG Page
  Press the EPG button to enter EPG mode (electronic program guide). Use the Up/Down buttons to choose a channel and check the program list for the next two sessions. To return to normal viewing of the channel, press the OK button. To check the complete program list for a day, press the Play button to display it. Press the Up/Down buttons to obtain detailed information. This information will be shown to the right of the program list. When you have chosen a program, use the OK button to preset the time for changing channel to make sure that you do not miss the program.
- TV/RADIO
  Press the TV/RADIO button to select the TV or radio channels.

9. TROUBLESHOOTING

If you experience problems with this receiver or its installation, in the first instance please read carefully the relevant sections of this User Manual and this Troubleshooting section.

Problem	Possible solution
No power	Check that the battery is properly charged. If not then charge the battery by connecting the power adapter Check that the player is switched on. Press the STANDBY button
No picture	Check that the screen is switched on
Poor quality picture	Check the disc for fingerprints and clean with soft cloth, wiping from the center to the edge Check that the disc is compatible with the TV format (PAL/NTSC) Check the antenna cable and the antenna installation (using an amplifier may improve signal quality)
Black and white picture	Check that the disc is compatible with the TV format (PAL/NTSC)
Picture interference	Place the unit as far away as possible from any sources of interference or emission (e.g. radios, etc.)
Remote control not working	Aim the remote control directly at the sensor on the front of the player. Remove any obstacles between the remote control and the sensor. Check the polarity of the batteries. Replace the batteries if necessary
No sound	Check the audio connections If using a Hi-Fi amplifier, try another sound source Clean the disc The disc may be damaged. Try another one
Disc cannot be played	Make sure that the disc is placed correctly in the disc tray
Improper functioning	Strong interference may disturb normal operation of this unit. Just reset the player by disconnecting and reconnecting the power cord

10. SPECIFICATIONS

Item	Specification	
Connectors	RF in	IEC 169-2 female connector
	Stereo headphones	3.5 mm jack
	USB	Multimedia playback FAT32 Some external hard disks may not be supported
	A/V out	RCA, Composite video (CVBS) + audio L/R
Power	Input	AC 100—240 V 50/60 Hz
	Consumption	15 W max.
Supported discs and files	DVD-Video, DVD+R/RW, DVD-R/RW, CD-DA, CD-R/RW MP3, JPEG, VCD2.0, MPEG4, Xvid (AVI)	
Video	TV System	PAL, NTSC
	Video output	Composite video 1.0 Vp-p 75 Ohm
Audio	Audio output	Analog audio output 2.0V (RMS) / 10 kOhm
	Frequency response	20Hz-20kHz +/- 3dB
Dimensions		206 x 160 x 40 mm (LxWxH)
Weight		1 kg (approx)

Specifications are subject to change without further notice.

WARRANTY

Energy Sistem Soyntec S.A. warrants its products to be free from defects in materials and workmanship at the time of purchase.
The warranty period is 36 months from the date of purchase.

WARRANTY PROCEDURE

- Visit the Support section at http://support.energysistem.com and select your product to view the FAQ (Frequently Asked Questions). The solution to your problem is very likely to have been already published there. You will also be able to download user manuals, user guides, drivers and updates.
- If you cannot find an appropriate solution in the Support section, you may send us your enquiry or warranty service request by email: support@energysistem.com
- Alternatively, you may prefer to contact the distributor from which you purchased the product, presenting the purchase receipt or invoice.

Specifications are subject to change without notice.
© 2009 by Energy Sistem®. All rights reserved.

TRADEMARKS.

All company, brand and product names are trademarks or registered trademarks of their respective companies.

DECLARATION OF CONFORMITY

Manufacturer Name: Energy Sistem Soyntec S. A.
Address: Pol. Ind. Finestrat – C/ Calpe, 1 – 03509 Finestrat Alicante
Tel: 902 388 388
Fax: 902 119 034
NIF: A53107488
We declare under our own exclusive responsibility that the product:
Energy Sistem® Portable DVD Player with DVB-T Energy™ M3700
Is in compliance with the essential directives, norms and standards of the European Union 89/336/EEC (EMC Directive).
Manufacturing country: China